



MMC INSTRUCTION SHEET

MMC Cocaine Trace Wipes

APPLICATION:	The MMC Cocaine Trace Wipes have been especially developed to detect residues of cocaine on luggage, bags, suitcases, car interiors and clothing such as jeans etc.
SENSITIVITY:	(Lower Detection Level) is < 0.02 mg depending on the purity of the material to be tested.
USER INSTRUCTIONS:	Warning!! Use only when wearing (Latex) gloves. Flow sack: The wipes are sealed in a flow sack containing 10 sealed wipes. The wipes can be used several times. * Do not use the wipe again following a positive reaction and replace or clean the gloves * Do not use dry or soiled wipes.
COLOUR CHANGE:	If cocaine is present, the wipe will immediately change into a bright light blue colour. The discoloration depends on the amount of cocaine on the materials to be inspected. Blue lines or small blue spots on the wipe indicate the presence of cocaine.
PACKAGING:	* Contents of Flow sacks: 10 Wipes (Size 13.5 x 15 cm) (Product code: cocw10S)
Storage life:	The storage life of the Wipes in closed (sealed) packaging is one (1) year following the production date, but the storage life also depends on the way they are stored. High temperatures will shorten the life span. If the Wipes no longer feel moist, they can no longer be used. Store at <35 °C.
Safety:	Wearing (Latex) gloves is required to prevent any skin irritations. Used wipes (Z/micro 15.98) non woven material) can be disposed of with normal waste.
General information	The supplier is not responsible for damage to goods and/or persons as a result of the use of the cocaine trace wipes.

Manufactured by:

M.M.C. International B.V.
Frankenthalerstraat 16-18
4816 KA BREDA
The Netherlands
Phone: +31-76-5711140
Fax: +31-76-5719300
URL: www.narcotictests.com